


EN









computer or car charger, it will take 1-2 hours to

① **仅与一台手机,平板电脑,台式电脑,笔记本等带蓝牙** 翻开耳机挂坠线控的软胶塞,把充电线插入,连接充电器 使用数据线连接耳机USB,并且插入电脑。语音提示

CH



Why the bluetooth headphone's noise is so big? micro USB data cable.

Don't use poor quality or unsure quality micro data


USB cable to transmit the data.

Mifo i2 supports firmware upgrade.You can upgrade

upgrading,please keep USB connected well with y

Why bluetooth headset can't hear voice? nethous can be found in mile official website,

Why bluetooth headset signal is not stable?



CH





CH






EN











电脑。请勿使用无质量保证的USB充电线进行数据传输

服务支持-资料下载 栏目中查询(www.mifo.hk)。 Mifo i2固件升级需使用windows系统电脑进行,升级

蓝牙耳机不开机?

蓝牙耳机信号不稳定?

蓝牙耳机噪音过大?

CH

蓝牙耳机听不到声音?